

CarAlgo Quick Guide

The 4 essential steps to get started

1 Locate the OBD-II port

Usually under the dashboard, on the driver's side.

2 Plug in the CarAlgo Dongle

Insert it firmly. The blue LED blinks once the ignition is on.

3 Install the app and create your account

Download CarAlgo (App Store / Google Play), create your account with the Dongle's serial number (on its nameplate), then accept the requested permissions (location, Bluetooth, notifications).

4 Add your vehicle

In the app, tap "Add a vehicle", start the engine, then "Continue". Configuration happens automatically.

Tip: the first 10-15 minute trip lets the system automatically calibrate the sensors. Drive normally.